



GATOR SPACER
WIDTH TILE JOINT SPACER DISK
TDS Revision Date (dd/mm/yyyy): 24/01/2018



TECHNICAL DATA SHEET

Update: January 24, 2018
Make sure you have an updated technical data sheet on hand.
Canada and U.S. dial **1-855-847-7767** or (450) 624-1611

Description: **GATOR SPACER** provides uniform spacing and unparallelled horizontal and vertical stability to the system. Available in joint sizes of 1/8", 3/16" and 1/4" (3,2 mm, 4,8 mm and 6,4 mm).

Features:

- Provide's the perfect joint width between tiles.
- Spacer can be cut into either a half- or a quarter-unit using an utility knife to be used along the edge of a building or the Gator Tile Edge.
- Simply break the spacer bar's bridge to obtain a flat disk, used as a levelling center unit on large or long porcelain tiles. Ex; 24x36" or 8" x32"



For use on: The **GATOR SPACER** is installed directly on top of the Gator Base.

Installation instructions: Only **Gator Block Bond XP** glue is recommended to bond the Porcelaine tile to the **GATOR SPACER** providing a monolithic and interlocking structure.

Dimensions: **GATOR SPACER DIMENSIONS 1/8"**


- Diameter 6" (15 cm)
- Thickness 1/8" (3 mm)
- **Spacer bar 1/8" (3,2 mm)**
- Spacer height 1/2" (1 cm)

GATOR SPACER DIMENSIONS 3/16"

- Diameter 6" (15 cm)
- Thickness 1/8" (3 mm)
- **Spacer bar 3/16" (4,8 mm)**
- Spacer height 1/2" (1 cm)

GATOR SPACER DIMENSIONS 1/4"

- Diameter 6" (15 cm)
- Thickness 1/8" (3 mm)
- **Spacer bar 1/4" (6,4 mm)**
- Spacer height 1/2" (1 cm)



Packaging:	Product	Unit Size	Units per Box
	Gator Spacer 1/8"	6 BAGS OF 50 UNITS	300 UNITS PER BOX
	Gator Spacer 3/16"	6 BAGS OF 50 UNITS	300 UNITS PER BOX
	Gator Spacer 1/4"	6 BAGS OF 50 UNITS	300 UNITS PER BOX



Alliance Designer Products Inc.
225 Blvd. Bellerose West, Laval, Quebec, Canada H7L 6A1
Tel.: 450 624-1611 Fax : 450 624-1622 Toll free : 1 866-212-1611
www.alliancegator.com - Email : info@alliancegator.com